































<p><b>开放式通讯耳机</b> OPENEAR Air X3</p> <p>User Manual 使用说明书</p>	<p><b>佩戴方式</b></p>  <p><b>包装清单</b></p> 	<p><b>产品信息</b></p> <p>耳机型号: OPENEAR Air X3 耳机类型: 开放式蓝牙通讯耳机 蓝牙版本: 5.3 频率范围: 20-20kHz 连接距离: ≈10米 麦克风: 抗干扰麦克风, -42dB 电池容量: 180mAh聚合物锂电池 续航时间: ≈6小时(80%音量) 充电时间: ≈2小时 充电电压: DC 5V</p> 	<p><b>按键示意图</b></p>  <p><b>开关机</b></p> <p>开机: 长按多功能键3秒, LED白绿灯闪烁, 提示音: power on pairing; 关机: 长按多功能键3秒, LED绿灯闪烁, 提示音: power off.</p> 	<p><b>蓝牙连接</b></p> <p>打开蓝牙菜单, 选择"OPENEAR Air X3"进行连接, 提示音: connected.</p>  <p><b>接听/挂断电话</b></p> <p>单击多功能键.</p> 
<p><b>拒接来电</b></p> <p>来电时双击多功能键.</p>  <p><b>播放/暂停音乐</b></p> <p>单击多功能键.</p> 	<p><b>上/下一曲</b></p> <p>上一曲: 长按+键, 下一曲: 长按-键.</p> <p>长按</p>  <p><b>音量加/减</b></p> <p>音量加: 单击+键, 音量减: 单击-键.</p> 	<p><b>唤醒语音助手</b></p> <p>三击多功能键.</p>  <p><b>低电量报警</b></p> <p>当电池电量低于10%时, 每隔30秒绿灯闪烁3下, 提示音: battery low.</p> 	<p><b>恢复出厂设置</b></p> <p>关机状态下, 长按多功能键10秒.</p> <p>长按10秒</p>  <p><b>充电</b></p> <p>请使用DC 5V适配器为设备充电, 充电时绿灯常亮, 充满电白灯常亮.</p> 	<p><b>重要说明</b></p> <ol style="list-style-type: none"> <li>1. 长时间听大音量音乐可能会带来不适感, 请尽可能使用中等左右的音量, 避免长时间使用大音量;</li> <li>2. 无论音量大小, 使用耳机时都将影响您对周围环境的感知, 使用耳机时多加注意;</li> <li>3. 切勿拆解或改装耳机, 否则可能导致耳机故障或烧毁;</li> <li>4. 切勿削剪, 挤压耳机或将耳机投入火中;</li> <li>5. 耳机应避免烟火、高压设备;</li> <li>6. 不适合十岁以下儿童使用, 内含小零件;</li> <li>7. 请勿将其归入生活垃圾, 而将其送往当地相应的电器设备回收站.</li> </ol> <p>注意: 若用户因违反以上警告内容造成的人身财产损失, 本公司不承担任何责任.</p>

<p><b>Open-Ear Communication Headset</b> OPENEAR Air X3</p> <p>User Manual</p>	<p><b>How to Wear</b></p>  <p><b>What's In the Box</b></p> 	<p><b>Specifications</b></p> <p>Model: OPENEAR Air X3 Type: Open-Ear Communication Headset BT Version: 5.3 Frequency: 20Hz-20kHz Connection: ≈10m Microphone: -42dB Battery: 180mAh Play Time: ≈6h(80%volume) Charging Time: ≈2h Charging Voltage: DC 5V</p> 	<p><b>Button Control</b></p>  <p><b>Power On/Off</b></p> <p>Power On: Press &amp; hold the MFB for 3 sec, white &amp; green led flash, Prompt: power on pairing. Power Off: Press &amp; hold the MFB for 3 sec, Prompt: power off.</p> <p>hold for 3sec</p> 	<p><b>BT Connection</b></p> <p>Select "OPENEAR Air X3" in BT menu to connect. Prompt: connects.</p>  <p><b>Answer/Hang Up A Call</b></p> <p>Click the MFB once.</p> 
<p><b>Reject A Call</b></p> <p>Double click the MFB.</p>  <p><b>Play/Pause Music</b></p> <p>Click the MFB once.</p> 	<p><b>Previous/Next Track</b></p> <p>Previous Track: Press &amp; hold the button +. Next Track: Press &amp; hold the button -.</p> <p>hold</p>  <p><b>Volume Up/Down</b></p> <p>Volume Up: Click the button + once. Volume Down: Click the button - once.</p> 	<p><b>Voice Command</b></p> <p>Quick triple click the MFB.</p>  <p><b>Low Battery</b></p> <p>When battery is lower than 10%, prompt: battery low.</p> 	<p><b>Restore Factory Setting</b></p> <p>Under power-off mode, press and hold the MFB for 10sec.</p> <p>hold for 10sec</p>  <p><b>Charge</b></p> <p>Please use DC 5V adapter for charging. Green LED is on during charging. White LED is on after fully charged.</p> 	<p><b>Attentions</b></p> <ol style="list-style-type: none"> <li>1. Listening to loud music for a long time may cause discomfort, please use medium volume if possible. Do not use high volume for long periods of time.</li> <li>2. Using headphones will affect your perception of the surrounding environment. Pay more attention when using headphones.</li> <li>3. Do not remove or modify the headphone, as this may cause damage or burn out.</li> <li>4. Do not throw, twist on headphones or put them into a fire.</li> <li>5. Keep it away from fire, hydration and high pressure equipment.</li> <li>6. Not suitable for children under 10-year-old containing small parts.</li> <li>7. Do not classify it as household waste. Please send it to the local electrical equipment recycling station.</li> </ol> <p>Note: The company does not assume any responsibility for the loss of personal property caused by the violation of the above warnings.</p>