


EXPLODED VIEW AND PARTS LIST

MODEL: SC760C



ITEM	PART NO.	PART NAME	Q' TY	ITEM	PART NO.	PART NAME	Q' TY
1	B01-01-040080-02	SCREW	2	35	B01-04-050050-02	SCREW	2
2	AA58C-006B	MAGAZINE BODY	1	36	AA58A-042A	PIN	1
3	AA58A-022A	CLIP	1	37	AA58A-003A	SPRING	1
4	B01-01-040060-02	SCREW	3	38	B08-013000180	O-RING	1
5	AA58A-014A	SCREW	2	39	AA58A-029A	REAR VALVE	1
6	B02-015060-02	PIN	2	40	AA58A-035A	REFLECTOR CAP	1
7	AA58C-009A	SPRING	1	41	AA58A-001B	BODY	1
8	AA58C-007A	MAGAZINE SHOE	1	▲42	B08-007650180	O-RING	1
▲9	AA58A-021A	WINDING SPRING	1	▲43	B08-032000350	O-RING	1
10	AA58A-005A	ROLLER	1	44	AA58A-024B	PISTON	1
11	AA58A-018A	BRACKET	1	▲45	B08-040000150	O-RING	1
12	B02-025180-02	PIN	2	46	AA58A-023A	CYLINDER CAP	1
13	AA58A-Y09A1	MAGAZINE RALL	1	47	B04-01-050-02	SPRING WASHER	4
14	AA58C-010B	PUSHER	1	48	B01-01-050220-02	SCREW	4
15	B02-025100-02	PIN	2	49	AA06A-018A	AIR PLUG	1
16	B04-01-040-02	SPRING WASHER	1	50	AA58C-005A	LATCH	1
17	B01-01-050250-02	SCREW	2	51	AA58B-007A	SPRING LATCH	1
18	AA58A-010A	SIDE PLATE	2	52	B07-04-060-04	LOCKNUT	2
▲19	AA58C-001A	JAW I	1	53	B02-030180-02	PIN	3
▲20	AA58C-002A	JAW II	1	54	B07-04-050-04	LOCKNUT	2
21	AA58A-011A	BUSHING	2	55	AA58A-037A	SHIM	3
22	AA58C-013B	MAIN FIRING PIN	1	56	AA58A-038A	LOCKNUT	1
23	AA58A-007A	ROLLER	4	57	AA58A-004A	STRAIGHT PIN	2
24	AA58A-006B	TRIGGER	1	▲58	AA58C-008A	FIRING PIN	1
25	AA58A-036A	STEM	1	59	B04-02-060-02	FLAT WASHER	2
26	AA58A-030A	FRONT VALVE	1	60	B04-01-060-02	SPRING WASHER	1
27	B08-013000180	O-RING	1	61	GG12A	SHEATH	1
28	AA58A-034A	WASHER	2				
29	AA58A-032A	SUPPORT	4				
30	AA58A-031A	VALVE	2	101	AA58A-Y07A1	REAR VALVE SET	
▲31	B08-007800190	O-RING	4	102	AA58A-Y05A1	VALVE SET	
32	AA58A-033A	SPACER	1	103	AA58A-Y06A1	FRONT VALVE SET	
33	B01-01-040060-02-NL	SCREW	2	104	AA58C-Y01A2	DRIVER	
34	AA58A-025A	TRIGGER GUARD	1	105	AA58A-Y10A1	VALVE COMPOSE	

Remark: Items with "▲" are vulnerable parts

GBA58H00301

A2